

AceSeal

A/C REVITALIZER

IMPROVES A/C PERFORMANCE

DESCRIPTION: AceSeal A/C REVITALIZER (ASEZ-REV) is an air conditioning performance booster specially formulated to enhance cooling properties of new and old air conditioning and refrigeration systems by reducing mechanical friction. Ideal for use on heat pumps, split systems, mini-split units, packaged units, microchannel coils etc. AceSeal A/C REVITALIZER contains a highly polar molecule that works synergistically with compressor oil to improve the performance of air conditioning and refrigeration systems by increasing heat transfer in the condenser and evaporator coils. The polarized molecule bonds to the metal inside the system and by removing the insulated buildup of oil forms a conductive layer to improve heat transfer. Treats systems up to 5 tons.

FEATURES & BENEFITS

- **Enhances Cooling Properties of New and Old AC Systems**
- **Saves Energy**
- **Reduces Noise and Friction**
- **Extends Unit Working Life**
- **Compatible With All Oils & Refrigerants... Excluding Ammonia**

DIRECTIONS:

STEP 1: Step 1: Turn the a/c system on, and verify the unit is running. Connect AceSeal A/C REVITALIZER Inject to the low-side service port of the system. (This is generally the large line.).

STEP 2. Insure the valves on manifold gauge set are closed. Start by connecting the high side (red) line of manifold gauge set to the high side service port. Remove AceSeal A/C REVITALIZER from the Mylar bag and loosely connect the middle manifold hose (yellow) to the 1/4" SAE male fitting of the AceSeal A/C REVITALIZER being careful NOT to depress the Schrader core. Quickly open the high side manifold valve to purge air out of the yellow hose. Now close the high side manifold valve, and quickly tighten the yellow hose fitting to the injector.

STEP 3. Next rapidly open and close the high side valve of the manifold gauge allowing a small amount of liquid to flow through the yellow hose and AceSeal A/C REVITALIZER tube. With high side valve of the manifold gauge set closed, wait one minute for the yellow hose AceSeal A/C REVITALIZER to equalize to suction pressure. Disconnect AceSeal A/C REVITALIZER from suction service port and from manifold gauge set. Allow unit to run for at least one hour to insure product has circulated in the system. Recycle empty container.

PROFESSIONAL USE ONLY. KEEP OUT OF THE REACH OF CHILDREN.

PACKAGING 6 per case

Refer to product label & Safety Data Sheet for precautionary and First Aid Information. The SDS is available on the ACE website at www.acechempro.com

