

AceSeal EZ PRO AC/R ACID DR. A/C ACID ELIMINATOR

DESCRIPTION: AceSeal EZ PRO AC/R ACID Dr. (ASEZ-ACIDX) is a concentrated acid eliminator supplied in a patent pending hose injection delivery system that makes installation ... simple, fast and easy. AceSeal EZ PRO AC/R ACID Dr. is formulated to convert moisture/acid in the system to inert synthetic oil. The highly polar molecules in the formula bond with moisture/acid and, through the refrigeration process of going from liquid to vapor, produce inert a synthetic oil which enhances lubrication of the system. Treats systems up to 5 tons. Do not use in ammonia systems.

FEATURES & BENEFITS

- Eliminates Acid Build-Up in A/C Systems
- Protects Against Future Acid
- Converts Acid to an Inert Synthetic Oil
- Compatible with All Oils & Refrigerants...
Excluding Ammonia

DIRECTIONS:

STEP 1: Turn the a/c system on, and verify the unit is running. Connect AceSeal EZ PRO AC/R ACID Dr. inject to the low-side service port of the system. (This is generally the large line.)

STEP 2: Insure the valves on manifold gauge set are closed. Start by connecting the high side (red) line of manifold gauge set to the high side service port. Remove AceSeal EZ PRO AC/R ACID Dr. from the Mylar bag and loosely connect the middle manifold hose (yellow) to the 1/4" SAE male fitting of the AceSeal EZ PRO AC/R ACID Dr. being careful NOT to depress the Schrader core. Quickly open the high side manifold valve to purge air out of the yellow hose. Now close the high side manifold valve, and quickly tighten the yellow hose fitting to the injector.

STEP 3: Next rapidly open and close the high side valve of the manifold gauge allowing a small amount of liquid to flow through the yellow hose and AceSeal EZ PRO AC/R ACID Dr. inject. With high side valve of the manifold gauge set closed, wait one minute for the yellow hose AceSeal EZ PRO AC/R ACID Dr. to equalize to suction pressure. Disconnect AceSeal EZ PRO AC/R ACID Dr. from suction service port and from manifold gauge set. Allow unit to run for at least one hour to insure product has circulated in the system. Recycle empty container.

PROFESSIONAL USE ONLY. KEEP OUT OF THE REACH OF CHILDREN.

PACKAGING 6 per case

Refer to product label & Safety Data Sheet for precautionary and First Aid Information. The SDS is available on the ACE website at www.acechempro.com

